

POWER ACOUSTIK


PDR-340/PDR-340T

Flip-down/Detachable 3.4" Monitor

MP3/MP4 Player

AM/FM Radio

Built-in TV tuner (only for PDR-340T model)



Owner's Manual

Take the time to read through this owner's manual.

Familiarity with installation and operation procedures will help you obtain the best Performance from your new device.

Important Safeguards









- Using the device at temperature below -10°C may cause the breakage of the device.
BEFORE USING PLEASE HEAT UP THE PASSENGER COMPARTMENT TO THE RECOMMENDED TEMPERATURE!
- Read carefully through this manual to familiarize you with this high-quality sound system.
- Disconnect the vehicle's negative battery terminal while mounting and connecting the unit.
- When replacing the fuse, be sure to use one with an identical amperage rating. Using a fuse with a higher amperage rating may cause serious damage to the unit.
- Make sure that pins or other foreign objects do not get inside the unit; they may cause malfunctions, or create safety hazards such as electrical shock or laser beam exposure.
- If you have parked the car for a long time in hot or cold weather, wait until the temperature in the car becomes normal before operating the unit.
- DO NOT open covers and do not repair yourself. Consult the dealer or an experienced technician for help.
- Make sure you disconnect the power supply and aerial if you will not use the system for a long period or during a thunderstorm.
- Make sure you disconnect the power supply if the system appears to be working incorrectly, (For example: making unusual sounds, smelling strange, emitting smokes from inside or liquid having gotten inside it) Have a qualified technician check the system.
- The unit is designed for negative terminal of the battery, which is connected to the vehicle metal. Please confirm it before installation.
- Do not allow the speaker wires to be shorted together when the unit is switched on. Otherwise it may overload or burn out the power amplifier.
- Do not install the detachable panel before connecting the wire.
- Don't remove the detachable panel when encoding.


Contents

Important Safeguards.....	2
Contents.....	3
Accessories.....	4
Installation/Un-Installation	5
Wiring Connections	6
Front panel.....	8
Inner panel	8
Remote control.....	9
Remove battery.....	9
Main Menu	10
General Operation	10
Radio operation.....	13
USB/SD/MMC Operation	14
TV Opeartion(only for PDR-340T model).....	15
Anti-theft system	16
Troubleshooting guide	17
Specifcation.....	18


Accessories

Package contains the following accessories for installation and operation of the unit.

(1) Washer, Spring Washer, M5 Nut	1 each	
(2) Mounting Strap	1	
(3) Bolt 5*20	1	
(4) Screw 5*6	4	
(5) Mounting Collar	1	
(6) Release Key	2	
(7) Screw 5*20	1	
(8) Rubber Cushion	1	



Remote Control



User Manual

Power Acoustic




Power Acoustic

100% 3 Year Warranty


100% 3 Year Warranty

100% 3 Year Warranty

100% 3 Year Warranty



1x front panel protection case



ISO cable



Trim ring


Noted:
Product image may vary from the actual delivery

Installation/Un-Installation

First complete the electrical connections, and then check them for correctness.

Installation

This unit can be installed in any dashboard having an opening as shown on the picture. The dashboard should be 4.75 – 5.56 mm thick in order to be able to support the unit.




1. Insert mounting collar into the dashboard, and bend the mounting tabs out with a screwdriver.
Make sure that lock lever (※) is flush with the mounting collar (not projecting outward).

2. Secure the rear of the unit.
After fixing mounting bolt and power connector, fix the rear of the unit to the car body by rubber cushion.

3. Insert trim plate.
When you prepare to insert trim plate, please check its direction. Once it was up side down, it cannot be fixed.

Un-installation

Remove Trim Ring and insert Release Keys into left and right side-end holes as shown in below picture and pull the unit out of the dashboard.




Wiring Connections

Make sure you have good chassis ground. A good ground connection will eliminate most electrical noise problems. A good chassis ground requires a tight connection to the vehicle's metal chassis. The area around the ground connection should be clean, bare metal without rust, paint, plastic, dust, or dirt for a good electrical connection.

Caution: Do not interchange the connection of the wiring!!!

For some car models you may need to modify wiring of the supplied power cord. Contact your authorized car dealer before installing this unit.

(Only for PDR-340)




Using the ISO Connector

1. If your car is equipped with the ISO connector, then connect the ISO connectors as illustrated.
2. For connections without the ISO connectors, check the wiring in the vehicle carefully before connecting, incorrect connection may cause serious damage to this unit.
3. Cut the connector; connect the colored leads of the power cord to the car battery as shown in the color code table below for speaker and power cable connections.

Location	Function	Connector A	Connector B
		Connector A	Connector B
1			Rear Right(+)--Purple
2			Rear Right(--)--Purple/Black Stripe
3	Parking (GND)--Brown		Front Right(+)--Grey
4	Battery 12V (+)--Yellow		Front Right(--)--Grey/Black Stripe
5	Auto Antenna--Blue		Front Left(+)--White
6			Front Left(--)--White/Black Stripe
7	ACC(+)--Red		Rear Left(+)--Green
8	Ground--Black		Rear Left(--)--Green/Black Stripe

(Only for PDR-340T)




Using the ISO Connector

1. If your car is equipped with the ISO connector, then connect the ISO connectors as illustrated.
2. For connections without the ISO connectors, check the wiring in the vehicle carefully before connecting, incorrect connection may cause serious damage to this unit.
3. Cut the connector; connect the colored leads of the power cord to the car battery as shown in the color code table below for speaker and power cable connections.


Location	Function	Connector A	Connector B
		Connector A	Connector B
1			Rear Right(+)--Purple
2	Rear Camera--Yellow		Rear Right(--)--Purple/Black Stripe
3	Parking (GND)--Brown		Front Right(+)--Grey
4	Battery 12V (+)--Yellow		Front Right(--)--Grey/Black Stripe
5	Auto Antenna--Blue		Front Left(+)--White
6			Front Left(--)--White/Black Stripe
7	ACC(+)--Red		Rear Left(+)--Green
8	Ground--Black		Rear Left(--)--Green/Black Stripe

Front panel



- | | |
|--------------------------------------|---------------------------------------|
| 1) Power /Mute button | 9) MENU button |
| 2) Mode button | 10) AS/PS button |
| 3) Volume/OK button | 11) Play/Pause, Memory button |
| 4) BAND / Media select /Radom button | 12) LCD Screen |
| 5) SET button | 13) IR sensor |
| 6) Previous / Reverse button | 14) OPEN button |
| 7) EQ /LOUD button | 15) USB slot |
| 8) Next / Forward button | 16) AUX IN jack/ AV IN jack(optional) |


Inner panel



- | |
|--------------------------|
| 17) SD/MMC card slot |
| 18) Reset button |
| 19) Anti-Theft LED flash |

NOTE: When turn off the power, the unit will switch to standby mode unless cut the ACC power. The power light will continue lighting.

Remote control




- | | |
|-----------------------------|------------------------------|
| 1: MENU | 13: MUTE |
| 2: POWER | 14: AUDIO |
| 3: UP | 15: SUBTITLE |
| 4: BAND/M.SEL/RDM | 16: RIGHT/SEEK+/FAST FORWARD |
| 5: ENTER | 17: VOLUME PLUS |
| 6: LEFT/SEEK-/FAST BACKWARD | 18: SET |
| 7: DOWN | 19: VOLUME MINUS |
| 8: REPEAT/INT | 20: EQ/LOUD |
| 9: AS/PS | 21: SEL |
| 10: MODE | 22: SCALE/ROTATE |
| 11: DIGIT NUMBER | 23: GO TO |
| 12: PLAY/PAUSE | |

Remove battery

Note:

- The distance may vary according to the brightness of ambient light.
- If the remote is not used for an extended period of time, remove the battery to prevent possible damage from battery leakage and corrosion.
- Do not place any objects between the remote control unit and the sensor on the unit.
- Do not drop the remote control onto the floor; it will damage it beyond repair.
- Do not use the remote control unit, while simultaneously operating the remote control unit of any other equipment; they may interfere resulting in improper operation.
- The battery normally last for about one year although depending how often the remote control is used. If the remote control unit isn't working even when it is operated near the unit, replace the battery with a new battery of the same make and use only a lithium cell battery type: CR2025 (3V).
- Dispose empty batteries in accordance with your local governmental regulations.
- Do not short-circuit, disassemble, heat or dispose of fire or flames the battery.
- Keep the battery out of reach of children, should the battery be swallowed, immediately consult a doctor.




Main Menu

The best way to discover the program is to explore each screen in detail, and to find out how to move from one to another. Read this chapter for a guided tour.

Unit starts by displaying the Main menu.

This is the root of the screen hierarchy, you can simply take knowledge of the features.



General Operation

Reset the unit

Operating the unit for the first time or after replacing the car battery, you must reset the unit. Press OPEN button on the panel to open the panel and press RESET button to restore the unit to its original factory settings.

Power on or off

Press any button (except open button) to turn on the unit.

Long press POWER button on front panel or press power button on the RC to power off the unit..

Mode setting

Press the MODE button repeatedly to switch between inputs:

→ RADIO→USB→SD→TV→AUX IN/AV IN→SETTING→RADIO

(* available only if there is media device in SD, USB slot connection is OK.)

Volume/OK

Adjust the volume level by turning the VOL knob on the panel clockwise to increase or counterclockwise to decrease or pressing VOL+ or /VOL- on the RC to increase or decrease the volume.

In any mode, rotate VOL knob to select the file you want to playback, press the OK button to enter the next menu.

In Mp3 mode, when playing the music, press the OK button on the front panel, the music will start from the beginning.

In Photo mode, when playing the photo, press the OK button on the front panel to enter the photo setup menu.

In Video mode, when playing the video, press the OK button on the front panel, you will see the track number and running time on the screen

Sound Adjustments

Press the SEL button on the RC to select the audio settings consisting of following items:

EQ: Select the digital sound effect USER→FLAT→CLASSIC→POP→ROCK

BASS: Bass up/down.

TREBLE: Treble up/down.

BALANCE: Left/right Balance control.

FADER: Front/rear Fader control.

LOUDNESS: Set the loudness on or off.

BEEP: Keypad sound setting.

Rotate Volume knob on the front panel or press up/down arrow on the RC to select any items and then press OK button on the panel or Enter button on the RC to confirm the item.

Rotate Volume knob or press LEFT/RIGHT buttons on the RC to adjust the audio setting. Press OK button on the panel or Enter button on the RC to confirm and again press SEL button return to current mode.

Note:

- ◇ If the unit is turned off, all the settings of each mode will be saved.
- ◇ If cutting off battery power or resetting the unit, all the settings will return to factory default settings.

Mute function

Press POWER/MUTE button on the panel or MUTE button on the RC to turn the sound off. Press it again to resume the volume.

Loudness

Long press EQ/LOUD button on the RC or front panel to set loudness on or off.

EQ

Press the EQ button on the panel to choose sound effect in the sequence of USER→FLAT→CLASSIC→POP→ROCK.

Menu

Press MENU button on the front panel or the RC to return to previous menu.


Setup

Press SET button on the RC or front panel, or SET icon on the main menu to go to setup pages.

- 1) Rotate Volume knob on the front panel or press up/down arrow on the RC to select any items and then press OK button on the panel or ENTER button on the RC to confirm the item
- 2) Rotate Volume knob or press LEFT/RIGHT buttons on the RC to adjust the audio setting. Press OK button on the panel or Enter button on the RC to confirm.
- 3) Press SET button on the RC or front panel again return to current mode.

Sound

SETTINGS	EQ	FLAT	EQ: select the digital sound effect.
SOUND	Bass	-01	Bass: bass up/down.
DISPLAY	Treble	+02	Treble: treble up/down.
GENERAL	Balance	-04	Balance: Left/right Balance control.
RADIO	Fader	-01	Fader: Front/rear Fader control.
SYSTEM			



LONDNESS: Selecting loudness ON will emphasize the low frequency output.

BEEP: Keypad sound setting.

Display



Bright: set the LCD screen brightness up or down

Contrast: set contrast up or down

Saturation: set saturation up or down


General



Clock hour: select 12-hour or 24-hour clock display mode.

Clock set: Press number buttons to input the current time.

Radio



Area: Select radio broadcasting area.

Stereo: Select stereo on or off.

System information



Product Info: You can view detail system information including serial number of the software

Default Set: return to factory default setting or not

AUX IN

Connect an optional AUX cable to your external AUX device, then press the MODE button to switch to the AUX mode.

AV IN (OPTIONAL)

Connect an optional AV cable to your external AV device (such as a video camera), then press the MODE button to switch to the AV mode. Note: If there is no external video input, the TFT displays "NO SIGNAL".

Parking

When the car is stopped and the parking brake is working, the screen can display the video image, and otherwise the screen display warning information.

Radio operation

Band selection

In Radio mode, press BAND button on the RC or front panel to select your band of choice in the following sequence:



Manual tuning

To find a station, select a band first, then press and hold ◀◀ / ▶▶ buttons on the RC until Manual appear on the display. Then press repeatedly these buttons to search for the needed frequency upward or downward.

Auto tuning

To find a station, select a band first, then press ◀◀ / ▶▶ buttons on the panel or press ◀◀ / ▶▶ buttons on the RC, the automatic search will start downward or upward. It will stop when a station is found.

Select a station

Repeatedly press ◀◀ / ▶▶ buttons on the panel to select a present station downward or upward. Or press digital number (1-6) on the RC to select any present station.

Preset scan

In tuner mode, press the AS/PS on the panel or RC to scan the preset memorized station, each preset scan for 5 seconds. Press again to stop operation.

Auto store

In tuner mode, Press the AS/PS on the panel or RC and hold for 2 seconds to store radio stations with the best reception to the preset number automatically.

Manual store

In tuner mode, long press the number 1-6 buttons on the RC after you find the station you desired. The station will preset to the corresponding number.

In tuner mode, long press the MEM button on the front panel after you find the station you desired, then rotate the VOL knob to select the number 1-6 on the radio interface, press the VOL/OK button on the front panel to confirm. The station will preset to the corresponding number.

USB/SD/MMC Operation

USB Flash Memory

To play MP3/ MP4/ WMA files from a USB flash memory, insert a USB flash memory into the USB port on the right side of the unit. The unit will play automatically MP3/MP4/ WMA/JPEG files. Or repeatedly press the MODE button to select USB mode.

SD/MMC Card

To play MP3/ MP4/ WMA/JPEG files on a SD/MMC card, insert the card into the card slot (you should press the Open button on the panel to flip down front panel and insert the SD/MMC card into card slot.) The unit will play automatically MP3/MP4/ WMA/JPEG files. Or repeatedly press the MODE button to select SD mode.

Play/Pause

In Multimedia mode, press Play/Pause button on the RC or front panel to pause playback. Press again to resume playback.

Select track

Press the M.SEL button on the front panel or RC to select the playback mode: MUSIC MODE→PHOTO MODE→VIDEO MODE. Then press the UP/DOWN button on the RC, also you can rotate the VOL knob or press the ◀◀ or ▶▶ on the front panel to select the file you desired to playback. Press ENTER button on the front panel or RC to enter the next menu, press the MENU button on the front panel to turn to previous menu. Press the MENU button on the RC to back to main menu.

During playback press SEEK- ◀◀ or SEEK+ ▶▶ on the RC or front panel to play the previous or next track. You can play the tracks by pressing Play/Pause button. Press number button (0-9) on the RC to select the desired track and then press ENTER button on the RC to confirm playback.

Random playback

In Media file mode, long press RDM button on the RC or BAND button on the front panel to set random playback on or off.

Fast backward/forward

During playback press and hold repeatedly SEEK- ◀◀ or SEEK+ ▶▶ on the RC or the panel to activate fast backward or forward playing. With each pressing, the playback speed will increase.

While fast playback, press Play/Pause button on the RC to resume normal speed.

When fast backward/forward playback reaches the previous or next track, the unit will resume normal playback.

GOTO

During playback, press the GOTO button on the RC to select the playback time of the track or chapter. Input the start time you want the track or chapter to start. Press ◀◀ or ▶▶ button on the RC to select the time you want to set, such as, hour: minute: second. Press the DIGITAL NUMBER button or UP/DOWN arrow button on the RC to set the time. Press ENTER to confirm. The track or chapter will start from the time you set.

Repeat playback

During Mp3 or Video file playback, press RPT button on the RC repeatedly for repeat playing in different modes: Repeat one, and repeat all.

Scale/Rotate

During Photo file playback, press it on the RC in photo mode to rotate the image clockwise by 90 degrees. How many times the button is pressed, the image will be rotated the corresponding times. During Video file playback, press it on the RC in Video mode to set the display ratio: 4:3 → 16:9 → Full Screen.

Select audio language

During Video file playback, press AUIO button on the RC repeatedly to select the audio language to listen. (Available only with the Video file that support multi-language playback).

Select subtitle language

If your Video file supports multi-language subtitle, press SUB-T button on the RC repeatedly to switch among the supported language.

Photo Adjustments

During Photo file playback, press the ENTER button on the RC or OK button on the front panel to enter the photo set menu. Press the ◀◀ or ▶▶ button on the RC to select the item you want to set, such as ZOOM/Rotate/Slideshow/Interval/Scale. Press the UP/DOWN arrow button on the panel to select the selection you want set in the item menu, press ENTER button on the RC or front panel to confirm. Zoom selection: ×1→×2→×3→×4. Rotate selection: 90°→180°→270°→0°. Slideshow: Fade In Fade Out, Persian Blinds H, Persian Blinds V, Slide up, Slide down, etc. Interval selection: Fast, Middle, Slow. Scale selection: Auto, Original, Crop, Stretch.

TV Opeartion(only for PDR-340T model)

1. Connect TV antenna, and then press MODE button to select TV mode.
2. In TV mode, press the Play/pause button once to enter TV menu setting.
3. Press the ▲/▼ button on the remote control or turning the knob clockwise or counterclockwise on front panel to select one of the setup pages: Auto program => Manual program.
4. Press VOL button on front panel or ENTER button on remote control to enter the page.
5. Press the ◀◀ / ▶▶ button or turning the knob clockwise or counterclockwise on front panel to select the setting value.
6. Press VOL button on front panel or ENTER button on remote control again to confirm, press Play/pause to return to settings list.

TV MENU

Press the MEM button to enter the setup menu of TV.

Auto program (Auto seek mode)

● System

Select the menu item is to set TV system: NTSC=>PAL=>SECAM, press ENTER button on remote.

● Audio

Select this menu item is to set the TV sound system:

- 1) When system setting PAL, TV sound system can set B/G=>I=>D/K=>M/N, press ENTER on remote.
- 2) When system setting SECAM, TV sound system can set B/G=>I=>D/K, press ENTER on remote.
- 3) When system setting NTSC, M/N sound system can be selected only.

● Search

Select this menu item is to start searching and storing stations automatically.

Manual program (manual seek mode)

Storage

Select this menu item is to set the storage number.

- **System**

Select this menu item is to set TV system: SECAM => NTSC =>PAL, press ENTER button on the remote control to select.

- **Audio**

Select this menu item is to set the TV sound system:

- 1) When system settings PAL, press ENTER on remote or tap the screen button to select TV sound system: D/K=>M/N=> B/G=> I.
- 2) When system setting SECAM, TV sound system B/G=>I=>D/K.
- 3) When system setting NTSC, M/N sound system can be selected only.

Channel

Select this menu item is to set your desired searching channel, press ◀▶ button to select channel.

- **Fine**

Select this menu item is to fine TV tuning and sound until it achieves the best quality, press ◀▶ button on remote to adjust.

- **Memory**

Select memory on or off is to set whether memory the searched station or not, press ENTER on remote control to select.

Anti-theft system

Remove the panel

1. Press the PWR button to turn the power off.
2. Press OPEN button to detach the panel.
3. Pull the panel out.
4. Place the panel into the case and take it with you when you leave the car.

Remove the unit

1. Remove the panel and the trim plate.
2. Insert both T-Keys into hole on the front of the set until they lock.
3. Pull out the unit.

NOTE:

The source unit will turn off if the control panel is open longer than 60 seconds.
The LED light on the inner panel will twinkle in red when the ACC power is cut off.

Troubleshooting guide

Symptom	Cause	Solution
General No power	The car ignition is not on. The fuse is blown.	If the power supply is properly connected to the car accessory switch the ignition key to "ACC". Replace the fuse.
No sound	Volume is in minimum. Wiring is not properly connected.	Adjust volume to a desired level. Check wiring connection.
The operation keys do not work.	The built-in microcomputer is not operating properly due to noise. Front panel is not properly fixed into its place.	Press the RESET button. Reinstall the front panel.
The radio does not work; the radio station automatic selection does not work.	The antenna cable is not connected the signals are too weak.	Insert the antenna cable firmly select a station manually.

Specification

General	
Power supply:	12 V DC
Current consumption:	Max. 10 A
Maximum power output:	52W x 4 channels (Max.)
Compatible formats:	MP3/MP4/WMA/ JPEG/RMVB
Dimensions (W x D x H) / weight:	178 x 175 x 50 mm / 1.8 kg
ESP function:	120 sec. for MP3
Working temperature range:	-10°C - +60°C
TFT display	
Screen size:	3.4 inch
Resolution:	720*400 dot
Aspect ratio:	4:3/16:9
Contrast ratio:	400:1
Brightness:	250 cd/m2
FM Stereo Radio	
Frequency range(U.S.A AREA)	87.5 – 107.9MHz(Step 200KHz)
Frequency range(EUROPE AREA):	87.5 – 108MHz(Step 50KHz)
Frequency range(ASIA AREA)	87.5 – 108MHz(Step 100MHz)
Preset memory stations:	18
AM/MW Radio	
Frequency range(U.S.A AREA)	530kHz - 1710 KHz(Step 10KHz)
Frequency range(EUROPE AREA):	522kHz - 1620 KHz(Step 9KHz)
Frequency range(AISA AREA)	531kHz - 1602 KHz(Step 9KHz)
Preset memory stations:	12
Audio specification	
Maximum output:	2 Vrms (+/- 3 dB)
Frequency response:	20 Hz - 20 KHz
S/N ratio(A-vtd):	68 Db
DSP sound effect:	USER→FLAT→CLASSIC→POP→ROCK
Line out	
Line outs:	2 channel RCA line-out(only for PDR-340) 4 channel RCA line-out(only for PDR-340T)

Specifications are subject to change without notice. Mass and dimension are approximate.